90KG FOLDING SACK TRUCK

MODEL NO: CST980.V2

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY.

Refer to instruction manual

fig.1

1. SAFETY

✓   Always load evenly with the centre of gravity of the load as near the centre of the truck as possible.
✓   Obtain additional support for large or wide loads to prevent tipping.
✗   **DO NOT** overload the truck - see Specifications.
✗   **DO NOT** leave unattended, especially when loaded, unless the wheels are chocked or the truck is otherwise secured.
✗   **DO NOT** use truck on uneven ground and do not run over curbs or steps - use a ramp.
✗   **DO NOT** allow others to ride on the truck.
✗   **DO NOT** use the truck if any part is significantly damaged - pay particular attention to the wheels.

2. INTRODUCTION

Lightweight aluminium frame, weighs only 7kg yet has a carrying capacity of 90kg. Folding steel foot plate and telescopic handle with spring release means that trolley can be packed away in seconds. Large back support makes light work of oversized loads. Fitted with Ø150mm wheels for easy-rolling over rough ground. Ideal for business and home use.

3. SPECIFICATION

Model no CST980.V2
Height(s) 710-1080mm
Overall width 395mm
Platform depth.. 240mm
Wheel depth... Ø150mm

4. INTRODUCTION

Lightweight aluminium frame, weighs only 7kg yet has a carrying capacity of 90kg. Folding steel foot plate and telescopic handle with spring release means that trolley can be packed away in seconds. Large back support makes light work of oversized loads. Fitted with Ø150mm wheels for easy-rolling over rough ground. Ideal for business and home use.

5. ASSEMBLY

5.1.   Make sure the axle is clean from dust and dirt to allow free movement of the wheel.
5.2.   Place the sleeve (fig.1.2) onto the axle (fig.1.1), as far as it will go.
5.3.   Slide the wheel (fig.1.3) onto the axle, and complete by pushing the pin (fig.1.4) through the hole in the end of the axle.
5.4.   Repeat the operation for the other side.

6. OPERATION

6.1.   Firstly fold down the foot plate ready to accept a load (fig.2).
6.2.   To extend the handle push the spring loaded locking bar forward (fig.2A) and lift the handle upwards until it latches in its fully extended position.
6.3.   To lower the handle, push the spring loaded locking bar forward and push the handle downwards until it latches in the closed position.
6.4.   After use close the handle, fold up the foot plate and store in a safe dry place.
6.5.   Only use truck with handle fully closed or fully extended.


fig.2

Locking Bar

Extending Handle

Folding Foot Plate

Original Language Version

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. Please note that other versions of this product are available. If you require documentation for alternative versions, please email or call our technical team on technical@sealey.co.uk or 01284 757505.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Original Language Version

CST980.V2 Issue:2 (HF) 21/01/21