



| Item | Part No. | Description |
|------|------------|--------------------------|
| 1 | CP20VHG.01 | Back Cover |
| 2 | CP20VHG.02 | Housing Assembly |
| 3 | CP20VHG.03 | Motor Assembly |
| 4 | CP20VHG.04 | Heating Element Assembly |
| 5 | CP20VHG.05 | Switch Sleeve |
| 6 | CP20VHG.06 | Trigger Spring |
| 7 | CP20VHG.07 | Trigger |
| 8 | CP20VHG.08 | Safety Lock Assembly |
| 9 | CP20VHG.09 | Switch |
| 10 | CP20VHG.10 | PCB |

| Item | Part No. | Description |
|------|------------|-----------------------|
| 11 | CP20VHG.11 | LED Cover |
| 12 | CP20VHG.12 | Screw for Inner Cover |
| 13 | CP20VHG.13 | Inner Cover (Metal) |
| 14 | CP20VHG.14 | Front Cover |
| 15 | CP20VHG.15 | Battery Connector |
| 16 | CP20VHG.16 | Screw for Housing |
| 17 | CP20VHG.17 | Battery Terminal |
| 20 | CP20VHG.20 | Reduction Nozzle |
| 21 | CP20VHG.21 | Fish Tail Nozzle |
| 22 | CP20VHG.22 | Deflector Nozzle |

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.