


## Parts Information:

## **HVLP Gravity Feed Spray Gun 1.3mm Set-Up Model No: HVLP05**



Item	Part No.	Description	Qty
1	HVLP05-01	Gun Body	1
2	HVLP05-02	Air Baffle	1
3	HVLP05-03	Fluid Nozzle 1.3mm ( <b>Standard</b> )	1
	HVLP05-03A	Fluid Nozzle 1.2mm ( <b>Optional</b> )	1
	HVLP05-03B	Fluid Nozzle 1.4mm ( <b>Optional</b> )	1
4	HVLP05-04	Lock Ring Seal	1
5	HVLP05-05	Air Cap 1.3mm ( <b>Standard</b> )	1
	HVLP05-05A	Air Cap 1.2mm ( <b>Optional</b> )	1
	HVLP05-05B	Air Cap 1.4mm ( <b>Optional</b> )	1
6	HVLP05-06	Air Cap Seal	1
7	HVLP05-07	Locking Ring	1

Item	Part No.	Description	Qty
8	HVLP05-08	Air Adjusting Valve Rod	2
9	HVLP05-09	E-Clip 5mm	2
10	HVLP05-10	Air Adjusting Valve Seal	2
11	HVLP05-11	Air Adjusting Valve Housing	2
12	HVLP05-12	Knob, Air Adjustment, Knurled, Aluminium, Black	2
13	HVLP05-13	Air Adaptor	1
14	HVLP05-14	Trigger	1
15	HVLP05-15	Trigger Pin	1
16	HVLP05-16	E-Clip 3mm	2
17	HVLP05-17	Air Valve Shaft Sleeve (A)	1

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk

Page 1 of 2 HVLP05 Issue 1 6/12/22



## Parts Information:

## **HVLP Gravity Feed Spray Gun 1.3mm Set-Up Model No: HVLP05**

Item	Part No.	Description	Qty
18	HVLP05-18	Air Valve Shaft	1
19	HVLP05-19	Air Valve Seal (A)	1
20	HVLP05-20	Air Valve Housing	1
21	HVLP05-21	Air Valve Seal (B)	1
22	HVLP05-22	Air Valve Shaft Seal (B)	4
23	HVLP05-23	Air Valve Shaft Seal Guide	2
24	HVLP05-24	Air Valve Gasket	2
25	HVLP05-25	Air Valve Rod	1
26	HVLP05-26	Air Valve Rod Spring	1
27	HVLP05-27	Fluid Needle Adjusting Guide	1
28	HVLP05-28	Fluid Needle 1.3mm ( <b>Standard</b> )	1
	HVLP05-28A	Fluid Needle 1.2mm ( <b>Optional</b> )	1
	HVLP05-28B	Fluid Needle 1.4mm ( <b>Optional</b> )	1

Item	Part No.	Description	Qty
29	HVLP05-29	Fluid Needle Seat	1
30	HVLP05-30	Fluid Needle Spring	1
31	HVLP05-31	Knob, Needle Adjustment, Knurled, Aluminium, Black	1
32	HVLP05-32	Pattern Adjusting Valve Rod	1
33	HVLP05-33	Needle Packing	1
34	HVLP05-34	Needle Gasket	1
35	HVLP05-35	Packing Nut	1
36	HVLP05-36	Fluid Inlet	1
	HVLP05-37	Fluid Pot (not shown)	1
	HVLP05-S1.2	Complete Set-up 1.2mm ( <b>not shown</b> )	1
	HVLP05-S1.3	Complete Set-up 1.3mm (not shown)	1
	HVLP05-S1.4	Complete Set-up 1.4mm ( <b>not shown</b> )	1

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

01284 757500



01284 703534



sales@sealey.co.uk

