



Item	Part No.	Description
1	HU20050080086	Top Handle
2	HU11010010725	Side Cover
3	HU11120260039	Power Cable
4	HU12070020009	Solenoid Valve
5	HU20070800288	Rocker Switch
6	HU20050050197	Back Panel
7	HU11020012272	Fan Support
8	HU20070890227	Fan
9	HU11050020828	Main Control Board
10	HU11050110512	EMC Board
11	HU11050070294	Control Board
12	HU11010050553	Middle Panel
13	HU20070400404	Wire Feeder
14	HU11010042165	Bottom Panel
15	HU20300030019	Wire Feeder Support
16	HU12070020250	Torch Socket

Item	Part No.	Description
17	HU20050050288	Front Panel
18	HU12070030101	Conversion Cable
19	HU20070570196	Quick Socket (Euro)
20	HU12080020697	Earth Clamp and Cable
21	HU20200010282	Mig Torch
21.1	INV MIG200V220	Contact Tip
21.2	IMIG180.14	Conical Nozzle
22	HU20030305534	Selector Mode Switch
23	HU20070110017	Potentiometer Knob
24	HU11010060825	Front Support Panel
25	HU20030300791	Wire Feed Potentiometer Wire
26	HU20030300792	Voltage Potentiometer Wire
27	HU20030300790	Lamp Holder
28	HU11010020907	Side Panel
29	HU12020160855	Spool Holder
30	HU20050050270	Door Latch

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.