



POLYMASK/MASKING PAPER DISPENSER

1 X 900MM ROLL

MODEL NO: MK77

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions

1. SAFETY

- ✓ Ensure the dispenser is on a reasonably flat, level floor before loading.
- ✓ Ensure that all fittings are tight and secure.
- ✗ **DO NOT** use the dispenser for any purpose other than that for which it is designed.

2. INTRODUCTION

Single roll dispenser accepts 900mm rolls and can be used either horizontally or vertically. Durable lightweight design with wheels for easy manoeuvrability.

3. SPECIFICATION

Capacity:..... 1 x 900mm (roll width)
Max Weight Capacity: 20kg (roll weight)

4. CONTENTS

REFER TO PARTS LIST

5. ASSEMBLY

REFER TO PARTS LIST

NOTE: Before assembling, note the location of the "brake bar" (10) mounting holes in the base (3) in relation to the "cross bar" (5) and spring (12) mounting holes in the side frames (1,2).

- 5.1. Attach side frames (1,2) to base (3) with two M8 x 45 mm hex bolts (4).
✗ **DO NOT** tighten bolts.
- 5.2. Attach front "cross bar" (5) to lower set of holes in side frames with two M8 x 45 mm hex bolts (4). Tighten all bolts in base.
- 5.3. Slide "wheel axle" (6) through base and place two M12 flat washers on each end of the "wheel axle" (6).
- 5.4. Slide "fixed wheels" (8) on each end of the wheel axle.
- 5.5. Install the two "brake bars" (10) to base with M8 x 45 mm (4) as shown on the parts diagram.
- 5.6. Hook the springs (12), with the rubber spacer (13), into holes on each side frame.
- 5.7. Install the "tape reel" (16) to inside of both side frames as shown on the parts diagram.

6. MAINTENANCE

- 6.1. If in constant use, check the tightness of all fixings on a weekly basis.





ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



sales@sealey.co.uk



www.sealey.co.uk