



Item	Part No.	Description
6	TP201.06	Knob
7	TP201.07	Gauge
8	TP201.08	Filter Seat Assembly
9	TP201.09	Fume Collection Bottle
10	TP201.10	Control Valve, Suction/Depletion
11	TP201.11	Pressure Release Assembly
12	TP201.12	Filter
13	TP201.13	Tank Handle
14	TP201.14	Wheel, Swivel Castor
15	TP201.15	Wheel, Swivel Castor (w/Brake)
16	TP201.16	Tank
17	TP201.17	Gun Seat
--	TP201.01	Oil Suction Tube 1/2" (Not Shown)
--	TP201.02	Oil Suction Tube 3/8" (Not Shown)
--	TP201.03	Oil Suction Tube 5/16" (Not Shown)
--	TP201.04	Oil Suction Tube 4*6 (Not Shown)
--	TP201.05	Oil Suction Tube 3/8" (Small Dia.)(Not Shown)

Item	Part No.	Description
--	TP201.18	Outlet Hose Assembly (Not Shown)
--	TP201.A01	Air Inlet Connector (Not Shown)
--	TP201.A03	Tank Outlet Connector (Not Shown)
--	TP201.A04	Tank Inlet Connector (Not Shown)
--	TP201.A05	Filter Cartridge (Not Shown)
--	TP201.A06	Hose End Stowage (Not Shown)
--	TP201.A09	Air Inlet Regulator (Not Shown)
--	TP201.A10	Air Inlet Valve (Not Shown)
--	TP201.A12	Fume Venting System (Not Shown)
--	TP201.A13	Tank Pressure Relief Valve (Not Shown)
--	TP201.A14	Tank Pressure Relief Valve, Manual (Not Shown)
--	TP201.A15	Switch Valve, Suction In/Discharge Out (Not Shown)
--	TP201.19	European Female Coupling & Converter Assembly (Not Shown)
--	TP201.19A	Suction Tube Converter (Not Shown)
--	TP201.20	Female Connector (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.