



FENICE S.p.A.

Via del Lavoro, 1 - 36078 Valdagno (Vicenza) - ITALY
+39 0445 424888 www.fenice.com

TECHNICAL DATA SHEET – Leather Care Div.

FABRIC ORGANIC REMOVER

DESCRIPTION

Specific cleaner for blood stains.

Fabric Organic Remover is a specific water-based cleaner for cleaning blood stains from fabric. The product is easy to apply and does not leave residues.

HOW TO USE

Pre-Test: Dampen a white cloth with water only. Rub the fabric lightly to see if color is transferred to the cloth. If color is removed just with water, it is certain that any product will remove color, so in this case do not use the cleaner. If there is no color loss with water, repeat the test with **Fabric Organic Remover**, being sure that you are satisfied with the results.

Directions: Apply **Fabric Organic Remover** directly onto the blood stain and leave to act for a few minutes. Pad the area with a dry white cloth in order to absorb the blood molecules. Repeat the operation until the stain has completely disappeared.

PHYSICAL CONSTANTS	Standard Value	Test Method
Appearance	yellowish liquid	MDA 008
pH	9 ± 1	MDA 004
Density (g/cm ³)	1.01 ± 0.05	MDA 018

STORAGE	Rev.
Non-dangerous product. Store between +5/40°C.	07.2017

MINIMUM SHELF-LIFE – HANDLING INSTRUCTIONS

The product is guaranteed for its physical and quality characteristics 24 months from the date of production. It has to be kept in its original packaging, well sealed and stored following the conditions in our technical data.

This document is exclusively reserved for professional users.

All information regarding correct use and any hazardous content are available in the safety data sheets.

All our information and suggestions are supplied on the basis of our present knowledge, and are subject to careful tests. However, we cannot accept responsibility for the use of the product, which must be verified and evaluated for its suitability or otherwise by the customer. Declared physical constants are monitored in production and guaranteed by FENICE S.p.A.