



20V CORDLESS 3 IN 1 GARDEN TOOL - BODY ONLY

MODEL NO: **CP20VGT3**

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear eye protection



Wear protective gloves



Wear protective clothing



Wear ear protection



Keep out of rain



Wear safety footwear



Wear face shield

1. SAFETY

1.1. GENERAL POWER TOOL SAFETY WARNINGS

- WARNING!** Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.
- WARNING!** Ensure that Health & Safety, local authority and general workshop practice regulations are adhered to when using this tool and attachments.
- ✓ Save all warnings and instructions for future reference.

1.2. WORK AREA SAFETY

- ✓ Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- ✗ **DO NOT** operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- ✓ Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

1.3. PERSONAL SAFETY

- ✓ Stay alert, watch what you are doing and use common sense when operating a power tool. **DO NOT** use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- ✓ Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- ✓ Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.
- ✓ Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- ✗ **DO NOT** overreach. Keep proper footing and balance at all times to enable better control of the power tool in unexpected situations.
- ✓ Dress properly. **DO NOT** wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- ✓ If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.

1.4. POWER TOOL USE AND CARE

- ✗ **DO NOT** force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- ✗ **DO NOT** use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- WARNING!** Disconnect the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools.
- ✓ Store idle power tools out of the reach of children and **DO NOT** allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- ✓ Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- ✓ Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.

1.5. SERVICE

- ✓ Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained. Unauthorised parts may be dangerous and will invalidate the warranty.

1.6. SPECIFIC MULTI-TOOL SAFETY

- ✓ **WARNING!** Disconnect the battery and ensure that the cutting tools are at a complete standstill before changing accessories, servicing or performing any maintenance.
- WARNING!** Keep all guards and holding screws in place, tight and in good working order.
- ✓ Check regularly for damaged parts. A guard or other part that is damaged must be repaired/replaced before the tool is next used.
- ✓ Keep the tool clean for best and safest performance.
- ✓ Before each use check all attachments for condition. If worn or damaged replace immediately.
- ✓ **WARNING!** Risk assess the work area. Keep bystanders away from the work area. **DO NOT** operate with anyone or pets nearby. Check intended work area for wildlife.

- ✗ **DO NOT** use in bad weather conditions, especially when there is a risk of lightning. **DO NOT** expose to rain. Only use in good light.
- ✗ **DO NOT** use if tool vibrates abnormally, switch off, remove battery and then inspect.
- ✗ **DO NOT** touch hazardous moving parts. Allow to come to a complete stop first.
- ✗ **DO NOT** operate whilst tired, ill under the influence of alcohol or other intoxicating drugs.
- ✗ **DO NOT** overreach and keep balance at all times.
- ✗ **DO NOT** use if damaged. **DO NOT** operate with defective guards or shields or without safety devices.
- ✗ **DO NOT** use for a task it was not designed to perform.
- ✓ Store with the battery removed and separate from the machine, in a dry, childproof location.
- ❑ **WARNING!** Never allow children, persons with reduced physical sensory or mental capabilities or lack of experience and knowledge or people unfamiliar with these instructions to use the machine, local regulations may restrict the age of the operator.
- ❑ **WARNING! DO NOT** touch moving hazardous parts before the machine is disconnected from the battery and the moving hazardous parts have come to a complete stop.
- ✓ Keep all parts of the body away from the gardening tools. **DO NOT** remove cut material or hold material to be cut when blades are moving. Blades continue to move after the switch is turned off.
- ✓ Carry the tool by the handle with the attachments stopped and taking care not to operate any power switch. Proper carrying of the tool will decrease the risk of inadvertent starting and resultant personal injury from the gardening tools.
- ✓ When transporting or storing the tool, always fit the blade cover. Proper handling of the tool will decrease the risk of personal injury from the blades.
- ❑ **WARNING!** Check the area to be worked for foreign objects e.g. wire fences

2. INTRODUCTION

Cordless 3 in 1 garden tool – body only, is designed to make trimming and gardening quick and easy. Its ergonomic design and lock-in function make it comfortable and easy to use. There are 3 tool-less interchangeable functions which means you can select the grass shearing blade, the hedge trimmer blade for light trimming or the rake. Requires compatible 20V battery and mains charger, sold separately.

3. SPECIFICATION

Model No.....**CP20VGT3**
 Battery20V 2Ah - 6Ah Lithium-ion (not included)




Noise power/pressure86/73dB(A)
 Vibration/Uncertainty..... 3.82/1.5m/s²

4. OPERATION

- ❑ **WARNING:** Remove battery before fitting / removing parts or maintenance is carried out.
 - ❑ **WARNING:** Wear appropriate hand protection when fitting or removing parts or maintenance is carried out.
- NOTE:** When new, the batteries may have been shipped in a low charge state. Fully charge the batteries before using your tool.

4.1. Ensure that you have read, understood and comply with all the safety instructions in Section 1.

4.2. INSTALLING / REMOVING SHEARS



- 4.2.1. Set the tool on its back to expose the plastic cover (fig.1). Depress the tab and slide the cover forwards and away from the tool.
- 4.2.2. **Removing the Shears:** Lift shears cutting blades upwards and forwards to lift them off of the two pins and out of the body.
- 4.2.3. **Installing the shears:** With the shear blade drive mechanism facing downwards into the body, hold the shears at a slight angle and slide the mechanism into the body, locating the rectangular cut-outs in the mechanism into the corresponding lugs in the body (fig.3). Manipulate the mechanism such that the two holes in it line up with the pins in the body.

- 4.2.4. Press the shears firmly down to engage the drive mechanism.
- 4.2.5. Replace the plastic cover.

4.3. INSTALLING / REMOVING TRIMMER

4.3.1. Follow steps 4.2.1 to 4.2.5 above.

4.4. INSTALLING / REMOVING RAKE

4.4.1. Follow steps 4.2.1 to 4.2.5 above.

4.5. OPERATION

- 4.5.1. To release and operate the trigger, slide the security lock forward (fig.4).
- 4.5.2. To stop the machine, release the trigger and allow the security lock to slide back.



5. MAINTENANCE

- ❑ **WARNING:** Always disconnect the battery before carrying out any inspection, maintenance or cleaning.

5.1. GENERAL INSPECTION

- 5.1.1. Regularly check that all the fixings are tight.
- 5.1.2. Repairs should be carried out by an authorised service centre.

5.2. CLEANING

- **WARNING:** Always wear protective equipment including eye protection and gloves when cleaning this tool.
- 5.2.1. Keep your tool clean at all times. Dirt and dust will cause internal parts to wear quickly and shorten the device's service life.
- 5.2.2. Clean the body of your machine with a soft brush, or dry cloth.
- 5.2.3. Never use caustic agents to clean plastic parts. If dry cleaning is not sufficient, a mild detergent on a damp cloth is recommended.
- 5.2.4. Water must never come into contact with the body of the tool. Ensure the tool is thoroughly dry before using it.

5.3. LUBRICATION

- 5.3.1. Lightly lubricate all moving parts at regular intervals with a suitable lubricant. See Sealey.co.uk for our range of lubricants.

5.4. STORAGE

- 5.4.1. Store this tool carefully in a secure, dry place out of the reach of children. Ensure all blade covers are fitted.

□ **WARNING! – Risk of Hand Arm Vibration Injury.**

This tool may cause Hand Arm Vibration Syndrome if its use is not managed adequately. This tool is subject to the vibration testing section of the Machinery Directive 2006/42/EC. This tool is to be operated in accordance with these instructions.

Grass Shear Measured vibration emission value (a)..... 3.65m/s²

Grass Shear Uncertainty value (k):..... 1.5m/s²

Hedge Trimmer Measured vibration emission value (a).....3.71m/s²

Hedge Trimmer Uncertainty value (k):.....1.5m/s²

Raker Measured vibration emission value (a).....3.82m/s²

Raker Uncertainty value (k):.....1.5m/s²

Please note that the application of the tool to a sole specialist task may produce a different average vibration emission. We recommend that a specific evaluation of the vibration emission is conducted prior to commencing with a specialist task.

A health and safety assessment by the user (or employer) will need to be carried out to determine the suitable duration of use for each tool.

N B: Stated Vibration Emission values are type-test values and are intended to be typical.

Whilst in use, the actual value will vary considerably from and depend on many factors.

Such factors include; the operator, the task and the inserted tool or consumable.

NB: ensure that the length of leader hoses is sufficient to allow unrestricted use, as this also helps to reduce vibration.

The state of maintenance of the tool itself is also an important factor, a poorly maintained tool will also increase the risk of Hand Arm Vibration Syndrome.

Health surveillance.

We recommend a programme of health surveillance to detect early symptoms of vibration injury so that management procedures can be modified accordingly.

Personal protective equipment.

We are not aware of any personal protective equipment (PPE) that provides protection against vibration injury that may result from the uncontrolled use of this tool. We recommend a sufficient supply of clothing (including gloves) to enable the operator to remain warm and dry and maintain good blood circulation in fingers etc. Please note that the most effective protection is prevention, please refer to the Correct Use and Maintenance section in these instructions. Guidance relating to the management of hand arm vibration can be found on the HSC website www.hse.gov.uk - Hand-Arm Vibration at Work.



ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



BATTERY REMOVAL

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 36 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk