

3W SMD & 1W COB LED ALUMINIUM PENLIGHT MODEL NO: LED016

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



instructions

1. SAFETY

1.1. GENERAL

- **DO NOT** shine directly into your, another person's or an animal's eyes.
- **× DO NOT** allow children to use the torch.
- **DO NOT** use the torch if you suspect that the battery or the torch casing is damaged.
- **DO NOT** leave batteries in a discharged state. Before storage remove batteries.
- 1.2. BATTERY SAFETY
 - WARNING! To reduce the risk of burns or fire:
 - **x DO NOT** attempt to open the batteries.
 - **DO NOT** crush, puncture, short contacts or dispose of in fire or water.
 - DO NOT expose to temperatures above 60°C (140°F).
 - ✓ Replace only with the batteries designed for this product.
 - ✓ Recycle or dispose of used batteries as stipulated by local regulation.
 - If the electrolyte in the batteries gets on your skin, rinse thoroughly with water. If it gets in your eyes, rinse thoroughly with cool water and seek immediate medical attention.

2. INTRODUCTION

Powerful, precise and pocket-sized penlight. 1W COB gives extremely bright light with up to 50 lumen output. 3W SMD side light with up to 55 lumen output. On/off fingertip switch. Powered by 1 x AAA battery (not included).

3. SPECIFICATION


LED016
1 x AAA (Not included)
COB/SMD - 50lm/55lm
3hrs

4. OPERATION

- 4.1. Unscrew the end of the pen.
- 4.2. Place one 1.5V AAA battery into the pen observing the "+" "-" polarity.
- 4.3. Replace the barrel of the pen light.
- 4.4. The light sequence is as follows: Firstly press the top button to turn SMD LED on, press again to turn SMD LED off, press to turn COB on, then press to turn COB off (fig.1).

5. MAINTENANCE

- 5.1. Keep the torch clean by wiping with a damp cloth.
- 5.2. Remove batteries if not being used for a long period of time.
- 5.3. Store torch and batteries in a dry childproof area.





ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



WEEE REGULATIONS

Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE). When the product is no longer required, it must be disposed of in an environmentally protective way. Contact your local solid waste authority for recycling information.



BATTERY REMOVAL: SEE SECTION 4

Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd are required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme. Jack Sealey Ltd Batteries Producer Registration Number (BPRN) is BPRN00705.

Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR 01284 757500 @ @ sales@sealey.co.uk @ www.sealey.co.uk